

## Rhenocoll Weißleimverzögerer VP 326 (retarder for PVAC glue)

**Art. No.: A1096**

### **Application areas:**

As an addition to Rhenocoll PVAC glues, such as Rhenocoll Standard, Extra, Spezial, Super W or Propellerleim. Used to prolong the open time.  
For professional use.

### **Advantages:**

Thanks to the addition of Rhenocoll-Weißleimverzögerer VP 326 the open time of the glues can be increased to a maximum of 60 min. Therefore, glues with special water and temperature resistance - although these glues generally only allow very short open times - can be used for time-consuming glueing. Add only as much retarder as required by open time. Mixture can be stored for an unlimited time and adhesion or final durability do not change.

### **Technical conditions:**

Addition quantity / open time (guidelines): An addition of max. 6% can increase the open time to a max. of up to 60 min.

The quantities added will result in varying open times, which have to be tested beforehand; depending on the type of glue, temperature and type of glueing, as well as type of wood.

The bonding times for wood elements will be increased significantly! Recommended is over night; however, you should conduct your own tests; bonding time is changeable depending on quantity added and mixture.

**Storage:** Cool, no danger of frost

### **General note:**

When coating or painting the glued parts, test first, if a discoloration occurs when the joint area comes in touch with the coating. This can occur when using PUR lacquers, especially when PUR hardener or other isocyanates exist in excess.

### **Ecology:**

According to the Federal Water Act §19 the product is hazardous to water, WGK (water hazard class) = 1

### **Labeling:**

VbF : none  
GGVE/GGVS: class 3, character 31 c  
Ordinance on Hazardous Substances: Xi irritant

### **Supply form:**

750 ml can - 6 cans in a carton  
5 liter jug

## Safety advice:

R 36 Irritant to the eyes.

S 24/25 Avoid contact with skin and eyes.

S26 In case of contact with skin and eyes, rinse immediately with plenty of water and seek medical advice.

## Service:

Our service team for application technology is available to you at any time without obligation.

**Phone: ++49 (0)6384 99 38 - 0**

**Fax: ++49 (0)6384 99 38 - 112**

**Email: [info@rhenocoll.de](mailto:info@rhenocoll.de)**

The information given within is without obligation and is based on practical experience as well as on experiments which we have carried out and are not attribute guaranties in the sense of the newest BGH legal requirements. We recommend that in any case users carry out their own tests since we have no influence over the large diversity of materials and their processing. No liability for the manufacturer can be derived from the contents of this data sheet. Statements going beyond or deviating from the contents of this data sheet require the written confirmation of the company headquarters. Our General Terms & Conditions apply in any case.

With the release of this Technical Data Sheet all previous versions become obsolete.